




PRESSURE/TORQUE CONVERSION CHART



PRESSURE IN PSI	FT. LBS.	N-m
1000	270	366
1200	330	447
1400	390	529
1600	465	630
1800	520	705
2000	600	813
2200	675	915
2400	740	1003
2600	800	1085
2800	865	1173
3000	930	1261
3200	990	1342
3400	1050	1424
3600	1120	1518
3800	1180	1600
4000	1240	1681
4200	1300	1763
4400	1360	1844
4600	1425	1932
4800	1490	2020
5000	1560	2115
5200	1585	2149
5400	1680	2278
5800	1740	2359
6000	1800	2440
6200	1850	2508
6400	1900	2576
6600	1960	2657
6800	2020	2739
7000	2080	2820
7200	2150	2915
7400	2210	2996
7600	2270	3078
7800	2330	3159
8000	2395	3247
8200	2460	3335
8400	2535	3437
8600	2585	3505
8800	2645	3586
9000	2725	3695
9200	2780	3769
9400	2850	3864
9600	2910	3945
9800	2975	4034
10000	3030	4108



For Reference Only