



PRESSURE/TORQUE CONVERSION CHART

8HP

**PRESSURE IN
PSI**

FT. LBS.

N-m

1000	762	1033
1200	927	1257
1400	1088	1475
1600	1242	1684
1800	1406	1906
2000	1561	2116
2200	1729	2344
2400	1902	2579
2600	2071	2808
2800	2225	3017
3000	2392	3243
3200	2545	3451
3400	2722	3691
3600	2885	3912
3800	3041	4123
4000	3212	4355
4200	3369	4568
4400	3535	4793
4600	3702	5019
4800	3865	5240
5000	4027	5460
5200	4191	5682
5400	4357	5907
5600	4520	6128
5800	4688	6356
6000	4853	6580
6200	5019	6805
6400	5178	7020
6600	5332	7229
6800	5494	7449
7000	5665	7681
7200	5840	7918
7400	5995	8128
7600	6168	8363
7800	6333	8586
8000	6498	8810
8200	6665	9037
8400	6829	9259
8600	7000	9491
8800	7160	9708
9000	7328	9935
9200	7495	10162
9400	7657	10381
9600	7832	10619
9800	8000	10847
10000	8100	10982

