



PRESSURE/TORQUE CONVERSION CHART

8IBT

PRESSURE IN PSI	FT. LBS.	N-m
1000	719	975
1200	866	1174
1400	1014	1375
1500	1087	1474
1600	1161	1574
1800	1308	1773
2000	1456	1974
2200	1604	2175
2400	1752	2375
2600	1900	2576
2800	2049	2778
3000	2197	2979
3200	2345	3179
3400	2493	3380
3600	2642	3582
3800	2791	3784
4000	2939	3985
4200	3088	4187
4400	3237	4389
4600	3387	4592
4800	3536	4794
5000	3685	4996
5200	3832	5195
5400	3984	5402
5600	4134	5605
5800	4284	5808
6000	4433	6010
6200	4583	6214
6400	4734	6418
6600	4883	6620
6800	5033	6824
7000	5183	7027
7200	5334	7232
7400	5484	7435
7600	5634	7639
7800	5784	7842
8000	5935	8047
8200	6085	8250
8400	6235	8453
8600	6386	8658
8800	6536	8862
9000	6686	9065
9200	6837	9270
9400	6988	9474
9600	7138	9678
9800	7289	9882
10000	7440	10087

